

Intelligent Voice Recognition & Automation Assistant

Test cases :

TC ID	Module	Test Scenario	Test Steps	Expected Result	Priority	Result (Pass/Fail)
TC-001	Voice Recognition	Detect microphone	Start NOVA	Microphone detected	High	
TC-002	Voice Recognition	Capture voice	Speak "Open Notepad"	Voice captured	High	
TC-003	Voice Recognition	Speech-to-text	Speak valid command	Correct text generated	High	
TC-004	Voice Recognition	Continuous listening	Speak multiple commands	All commands processed	High	
TC-005	Voice Recognition	Background noise	Speak with noise	Correct recognition	High	
TC-006	Voice Recognition	Invalid speech	Speak unclear words	Error message displayed	High	
TC-007	Voice Recognition	Silence	Don't speak	Ask user to repeat	Medium	
TC-008	Voice Recognition	Empty audio	Start recognition without speaking	No crash	Medium	
TC-009	Voice Recognition	Long command	Speak long sentence	Command processed	Medium	

TC-010	Voice Recognition	Fast speech	Speak quickly	Recognized correctly	Medium	
TC-011	Voice Recognition	Slow speech	Speak slowly	Recognized correctly	Medium	
TC-012	Voice Recognition	Accent handling	Speak with different accent	Supported accent recognized	Medium	
TC-013	Voice Recognition	Unsupported language	Speak unsupported language	Language error shown	Medium	
TC-014	Voice Recognition	Mic permission denied	Disable microphone	Permission error	High	
TC-015	Voice Recognition	Mic disconnected	Remove microphone	Device error shown	High	
TC-016	Voice Recognition	Special characters	Speak unsupported phrases	Handled safely	Low	
TC-017	Voice Recognition	Repeat command	Repeat same command	Executes each time	Medium	
TC-018	Voice Recognition	Recognition speed	Speak command	Response within expected time	High	
TC-019	Voice Recognition	Forward command	Speak valid command	Sent to Command Processor	High	
TC-020	Voice Recognition	Stability	Execute 100 commands	No crash	High	
TC-021	Command Processing	Valid command routing	Say "Open Chrome"	Routed to Launcher	High	
TC-022	Command Processing	Invalid command	Say unknown command	Invalid command message	High	
TC-023	Command Processing	Multiple commands	Speak sequential commands	Correct routing	High	

TC-024	Command Processing	Mixed-case command	Speak command differently	Recognized	Medium	
TC-025	Command Processing	Extra spaces	Command with pauses	Correct parsing	Medium	
TC-026	Command Processing	Blank command	No recognized text	No processing	Medium	
TC-027	Command Processing	Unknown module	Unsupported request	Graceful failure	High	
TC-028	Command Processing	Website command	Say "Open Google"	Website module called	High	
TC-029	Command Processing	File command	Say "Open Downloads"	File module called	High	
TC-030	Command Processing	Email command	Say "Read my emails"	Email module called	High	
TC-031	Registry Launcher	Launch Notepad	Say "Open Notepad"	Notepad opens	High	
TC-032	Registry Launcher	Launch Calculator	Say "Open Calculator"	Calculator opens	High	
TC-033	Registry Launcher	Third-party app	Say "Open VS Code"	VS Code opens	High	
TC-034	Registry Launcher	Invalid app	Say unknown app	App not found message	High	
TC-035	Registry Launcher	Registry lookup	Search installed app	Correct path returned	High	
TC-036	Registry Launcher	No hard-coded path	Launch app	Launch from Registry	High	
TC-037	Registry Launcher	Missing registry entry	Remove entry	Error displayed	Medium	
TC-038	Registry Launcher	Admin app	Launch admin app	Proper handling	Medium	

TC-039	Registry Launcher	Multiple launches	Launch apps one by one	All launch correctly	Medium	
TC-040	Registry Launcher	Performance	Launch app	Opens quickly	Medium	
TC-041	Windows Startup	Enable startup	Turn on auto-start	Registry updated	High	
TC-042	Windows Startup	Disable startup	Turn off auto-start	Startup removed	High	
TC-043	Windows Startup	Automatic launch	Restart Windows	NOVA starts automatically	High	
TC-044	Windows Startup	Welcome message	Login to Windows	Personalized greeting	Medium	
TC-045	Windows Startup	Username retrieval	Start application	Correct username shown	Medium	
TC-046	Windows Startup	Background execution	Login	Runs in background	High	
TC-047	Windows Startup	Duplicate startup	Enable twice	No duplicate entry	Medium	
TC-048	Windows Startup	Registry permission	Restrict registry	Error handled	Medium	
TC-049	Windows Startup	Startup disabled	Restart PC	NOVA does not auto-start	High	
TC-050	Windows Startup	System compatibility	Test on Windows versions	Works correctly	High	
TC-051	Website Opening	Open Google	Say "Open Google"	Google opens in default browser	High	
TC-052	Website Opening	Open YouTube	Say "Open YouTube"	YouTube opens	High	

TC-053	Website Opening	Open GitHub	Say "Open GitHub"	GitHub opens	High	
TC-054	Website Opening	Open Stack Overflow	Say "Open Stack Overflow"	Stack Overflow opens	Medium	
TC-055	Website Opening	Open website without "www"	Say "Open Facebook"	Correct website opens	Medium	
TC-056	Website Opening	Invalid website	Say random website name	Error message displayed	High	
TC-057	Website Opening	No Internet	Disconnect internet and open website	Internet connection error shown	High	
TC-058	Website Opening	Browser unavailable	Remove default browser	Browser error displayed	Medium	
TC-059	Website Opening	Different browser	Change default browser	Website opens in new browser	Medium	
TC-060	Website Opening	Response time	Open website	Opens within acceptable time	Medium	
TC-061	Website Opening	Voice variation	Say "Launch Google"	Google opens	Medium	
TC-062	Website Opening	Upper/Lower case	Speak differently	Website identified correctly	Low	
TC-063	Website Opening	Website with space	Say "Open Google Maps"	Correct page opens	Medium	
TC-064	Website Opening	Repeated request	Open same website twice	Opens successfully each time	Low	

TC-065	Website Opening	Unsupported domain	Say invalid domain	Graceful failure	Medium	
TC-066	Email Automation	Login to email	Provide valid credentials	Login successful	High	
TC-067	Email Automation	Invalid login	Enter wrong password	Authentication failed	High	
TC-068	Email Automation	Read unread emails	Say "Read unread emails"	Unread emails displayed/read	High	
TC-069	Email Automation	No unread emails	Inbox empty	"No unread emails" message	Medium	
TC-070	Email Automation	Compose email	Dictate recipient and message	Email draft created	High	
TC-071	Email Automation	Send email	Confirm sending	Email sent successfully	High	
TC-072	Email Automation	Invalid recipient	Enter invalid email address	Validation error displayed	High	
TC-073	Email Automation	Missing subject	Send without subject	Warning or email sent as per design	Medium	
TC-074	Email Automation	Empty message	Send blank email	Validation message displayed	Medium	
TC-075	Email Automation	Search by sender	Search sender name	Matching emails displayed	High	
TC-076	Email Automation	Search by subject	Search subject keyword	Correct emails displayed	High	

TC-077	Email Automation	Search nonexistent email	Search invalid keyword	No records found	Medium	
TC-078	Email Automation	New email notification	Receive new email	Voice notification played	High	
TC-079	Email Automation	Read email subject	Open received email	Subject spoken correctly	High	
TC-080	Email Automation	Read email body	Open received email	Body read correctly	Medium	
TC-081	Email Automation	Email with attachment	Open attachment email	Attachment identified	Medium	
TC-082	Email Automation	Multiple unread emails	Read inbox	All unread emails processed	Medium	
TC-083	Email Automation	Internet disconnected	Send email offline	Sending failed message	High	
TC-084	Email Automation	SMTP server unavailable	Disable SMTP	Appropriate error displayed	Medium	
TC-085	Email Automation	IMAP server unavailable	Disable IMAP	Read operation failed safely	Medium	
TC-086	Email Automation	Voice confirmation	Send email	Voice confirmation received	Low	
TC-087	Email Automation	Long email message	Dictate long content	Complete email captured	Medium	
TC-088	Email Automation	Special characters	Include symbols	Email preserved correctly	Low	

TC-089	Email Automation	Large inbox	Read inbox with many emails	Performance acceptable	Medium	
TC-090	Email Automation	Session timeout	Leave account idle	User prompted to log in again	Medium	
TC-091	File & Folder	Search existing file	Say "Find Report.docx"	File located	High	
TC-092	File & Folder	Search nonexistent file	Search random filename	File not found	High	
TC-093	File & Folder	Open file	Say file name	File opens successfully	High	
TC-094	File & Folder	Open folder	Say folder name	Folder opens	High	
TC-095	File & Folder	Create folder	Say "Create Project Folder"	Folder created	High	
TC-096	File & Folder	Create existing folder	Use existing folder name	Duplicate warning displayed	Medium	
TC-097	File & Folder	Rename file	Rename existing file	File renamed	High	
TC-098	File & Folder	Rename folder	Rename folder	Folder renamed	High	
TC-099	File & Folder	Cancel delete	Cancel confirmation	File remains unchanged	High	
TC-100	File & Folder	Delete file	Delete selected file and confirm	File deleted	High	

TC-101	File & Folder	Delete folder	Delete folder after confirmation	Folder deleted successfully	High	
TC-102	File & Folder	Cancel folder deletion	Select No when prompted	Folder remains unchanged	High	
TC-103	File & Folder	Rename non-existing file	Enter invalid filename	Error message displayed	Medium	
TC-104	File & Folder	Open unsupported file	Open unknown file type	Appropriate application prompt shown	Medium	
TC-105	File & Folder	Search file by partial name	Speak partial filename	Matching files displayed	Medium	
TC-106	File & Folder	Search folder by partial name	Speak partial folder name	Matching folders displayed	Medium	
TC-107	File & Folder	Open hidden file	Request hidden file	Opens if permission exists	Low	
TC-108	File & Folder	Open system folder	Say "Open Windows Folder"	Folder opens successfully	Medium	
TC-109	File & Folder	Access denied folder	Open protected folder	Permission denied message	High	
TC-110	File & Folder	Create folder with special characters	Create invalid folder name	Validation error displayed	Medium	
TC-111	File & Folder	Rename using invalid characters	Rename with invalid symbols	Rename prevented	Medium	
TC-112	File & Folder	Create nested folders	Create Parent/Child folder	Nested folders created	Medium	

TC-113	File & Folder	Open recently created folder	Open created folder	Folder opens correctly	Medium	
TC-114	File & Folder	Delete read-only file	Delete protected file	Warning displayed	High	
TC-115	File & Folder	Open file after rename	Rename then open	Renamed file opens	Medium	
TC-116	File & Folder	Search after deletion	Delete then search	File not found	Medium	
TC-117	File & Folder	Long filename	Open file with long name	Opens successfully	Low	
TC-118	File & Folder	File path with spaces	Open file inside spaced folder	Opens successfully	Medium	
TC-119	File & Folder	Multiple file operations	Create, Rename, Delete	All execute successfully	Medium	
TC-120	File & Folder	Performance	Search among thousands of files	Search completes efficiently	Medium	
TC-121	Reminder & Timer	Create reminder	"Remind me at 5 PM"	Reminder saved	High	
TC-122	Reminder & Timer	Reminder notification	Wait until reminder time	Voice reminder played	High	
TC-123	Reminder & Timer	Set timer	"Set timer for 2 minutes"	Timer starts	High	
TC-124	Reminder & Timer	Timer completion	Wait for timer	Alarm sounds	High	

TC-125	Reminder & Timer	Cancel timer	Cancel active timer	Timer stops	High	
TC-126	Reminder & Timer	Cancel reminder	Delete reminder	Reminder removed	High	
TC-127	Reminder & Timer	Edit reminder	Modify reminder time	Updated successfully	Medium	
TC-128	Reminder & Timer	View reminders	Request reminder list	All reminders displayed	Medium	
TC-129	Reminder & Timer	Multiple reminders	Create several reminders	All stored correctly	Medium	
TC-130	Reminder & Timer	Past time reminder	Set reminder in past	Validation message displayed	High	
TC-131	Reminder & Timer	Invalid date	Enter invalid date	Error shown	Medium	
TC-132	Reminder & Timer	Invalid time	Enter invalid time	Error shown	Medium	
TC-133	Reminder & Timer	Schedule application	Schedule Notepad	Opens at scheduled time	High	
TC-134	Reminder & Timer	Schedule website	Schedule Google	Opens automatically	Medium	
TC-135	Reminder & Timer	Restart after scheduling	Restart PC	Reminder persists	High	
TC-136	Reminder & Timer	Duplicate reminder	Create same reminder twice	Both handled correctly	Low	

TC-137	Reminder & Timer	Reminder with long text	Save long reminder	Stored successfully	Low	
TC-138	Reminder & Timer	Timer accuracy	Set 60-second timer	Expires near 60 seconds	High	
TC-139	Reminder & Timer	Simultaneous timers	Create two timers	Both execute correctly	Medium	
TC-140	Reminder & Timer	Reminder log	Complete reminder	Activity logged	Medium	
TC-141	Text-to-Speech	Speak greeting	Start NOVA	Welcome message spoken	High	
TC-142	Text-to-Speech	Read response	Execute command	Assistant speaks response	High	
TC-143	Text-to-Speech	Read notification	Receive reminder	Reminder spoken	High	
TC-144	Text-to-Speech	Read email subject	Read inbox	Subject spoken	High	
TC-145	Text-to-Speech	Adjust speech rate	Increase speed	Faster speech output	Medium	
TC-146	Text-to-Speech	Reduce speech rate	Decrease speed	Slower speech output	Medium	
TC-147	Text-to-Speech	Adjust volume	Increase/decrease volume	Volume changes correctly	Medium	
TC-148	Text-to-Speech	Long text output	Read long paragraph	Speech completes without interruption	Medium	

TC-149	Text-to-Speech	No speaker device	Disconnect speakers	Audio device error displayed	High	
TC-150	Text-to-Speech	Consecutive speech	Execute multiple commands	Speech responses occur sequentially	Medium	
TC-151	Sleep/Wake	Activate Sleep Mode	Say "Sleep"	Assistant stops listening	High	
TC-152	Sleep/Wake	Activate Wake Mode	Say "Wake Up"	Assistant resumes listening	High	
TC-153	Sleep/Wake	Ignore commands while sleeping	Say "Open Chrome" during sleep	Command ignored	High	
TC-154	Sleep/Wake	Wake with valid keyword	Say wake word	Assistant activates	High	
TC-155	Sleep/Wake	Invalid wake word	Say incorrect wake word	Assistant remains asleep	Medium	
TC-156	Sleep/Wake	Multiple sleep commands	Say "Sleep" repeatedly	No duplicate action	Low	
TC-157	Sleep/Wake	Multiple wake commands	Say "Wake Up" repeatedly	No duplicate action	Low	
TC-158	Sleep/Wake	Check assistant status	Request current status	Displays "Sleeping" or "Listening"	Medium	
TC-159	Sleep/Wake	Restart while sleeping	Restart NOVA	Previous state handled correctly	Medium	
TC-160	Sleep/Wake	Long sleep duration	Leave sleeping for hours	Wake works correctly	Medium	
TC-161	Language Selection	View language list	Open language settings	Available languages displayed	High	
TC-162	Language Selection	Select English	Choose English	English saved	High	

TC-163	Language Selection	Select Hindi	Choose Hindi	Hindi saved	High	
TC-164	Language Selection	Invalid language	Choose unsupported language	Error displayed	Medium	
TC-165	Language Selection	Restart after language change	Restart NOVA	Selected language loaded	High	
TC-166	Language Selection	Voice output language	Speak response	Response uses selected language	High	
TC-167	Language Selection	Switch languages repeatedly	Change several times	No errors	Medium	
TC-168	Language Selection	Save preference	Close application	Language retained	High	
TC-169	Language Selection	Missing language pack	Remove language file	Warning displayed	Medium	
TC-170	Language Selection	Default language	Fresh installation	Default language loaded	Medium	
TC-171	Voice Customization	Display voice list	Open voice settings	Voice options displayed	High	
TC-172	Voice Customization	Select Male voice	Choose Male	Voice changes	High	
TC-173	Voice Customization	Select Female voice	Choose Female	Voice changes	High	
TC-174	Voice Customization	Preview voice	Click Preview	Sample speech played	Medium	
TC-175	Voice Customization	Save selected voice	Save settings	Voice preference stored	High	
TC-176	Voice Customization	Restart application	Restart NOVA	Selected voice loaded	High	

TC-177	Voice Customization	Invalid voice profile	Select unavailable voice	Error displayed	Medium	
TC-178	Voice Customization	Change voice during speech	Switch voice while speaking	Next response uses new voice	Low	
TC-179	Voice Customization	Voice quality	Listen to response	Speech clear and understandable	Medium	
TC-180	Voice Customization	Default voice	Reset settings	Default voice restored	Medium	
TC-181	User Preferences	Save all settings	Modify preferences	Settings saved	High	
TC-182	User Preferences	Load preferences	Restart NOVA	Saved settings loaded	High	
TC-183	User Preferences	Update preferences	Change settings	Updated successfully	Medium	
TC-184	User Preferences	Reset preferences	Click Reset	Defaults restored	Medium	
TC-185	User Preferences	Save startup option	Enable auto-start	Preference saved	High	
TC-186	User Preferences	Save language preference	Change language	Preference retained	High	
TC-187	User Preferences	Save voice preference	Change voice	Preference retained	High	
TC-188	User Preferences	Corrupted preference file	Corrupt settings	Defaults loaded safely	Medium	
TC-189	User Preferences	Missing preference file	Delete settings file	New file created	Medium	
TC-190	User Preferences	Multiple preference updates	Modify repeatedly	Latest settings saved	Low	
TC-191	Activity Logging	Log voice command	Execute command	Command recorded	High	

TC-192	Activity Logging	Log application launch	Open Calculator	Launch recorded	High	
TC-193	Activity Logging	Log website opening	Open Google	Website action logged	Medium	
TC-194	Activity Logging	Log email sending	Send email	Email activity logged	High	
TC-195	Activity Logging	Log reminder creation	Create reminder	Reminder logged	Medium	
TC-196	Activity Logging	Log system error	Trigger error	Error stored in log	High	
TC-197	Activity Logging	Verify timestamp	Perform action	Correct date & time recorded	High	
TC-198	Activity Logging	View log history	Open logs	All records displayed	Medium	
TC-199	Activity Logging	Large log file	Execute many commands	Logging continues correctly	Medium	
TC-200	Activity Logging	Clear logs	Delete log history	Logs removed successfully	Medium	
TC-201	Settings Management	Open Settings	Say "Open Settings"	Settings menu opens	High	
TC-202	Settings Management	Close Settings	Exit settings menu	Returns to main screen	Medium	
TC-203	Settings Management	Change language from settings	Select another language	Language updated	High	
TC-204	Settings Management	Change voice from settings	Select another voice	Voice updated	High	
TC-205	Settings Management	Enable auto-start	Turn ON auto-start	Setting saved	High	

TC-206	Settings Management	Disable auto-start	Turn OFF auto-start	Setting saved	High	
TC-207	Settings Management	Login through settings	Enter valid credentials	Login successful	High	
TC-208	Settings Management	Logout	Click Logout	User logged out	High	
TC-209	Settings Management	Save modified settings	Save changes	Settings stored successfully	High	
TC-210	Settings Management	Cancel changes	Exit without saving	Previous settings retained	Medium	
TC-211	Settings Management	Invalid settings input	Enter unsupported value	Validation message displayed	Medium	
TC-212	Settings Management	Open settings via voice	Say "Change Settings"	Settings page opens	High	
TC-213	Settings Management	Load saved settings	Restart NOVA	Saved settings loaded	High	
TC-214	Settings Management	Reset all settings	Click Reset	Default settings restored	Medium	
TC-215	Settings Management	Missing settings file	Delete settings file	New default file created	Medium	
TC-216	Main Integration	Launch application after voice recognition	Speak "Open Calculator"	Voice → Command → Registry → App Launch successful	High	

TC-217	Main Integration	Open website using voice	Say "Open Google"	Website opens successfully	High	
TC-218	Main Integration	Create reminder by voice	Set reminder	Reminder created and stored	High	
TC-219	Main Integration	Read emails using voice	Say "Read unread emails"	Email module executes	High	
TC-220	Main Integration	Open folder by voice	Say folder name	Folder opens successfully	High	
TC-221	Main Integration	Voice → TTS flow	Give valid command	Spoken confirmation received	High	
TC-222	Main Integration	Sleep then wake	Sleep → Wake	Assistant resumes normally	High	
TC-223	Main Integration	Language + TTS	Change language then speak	TTS uses selected language	High	
TC-224	Main Integration	Voice customization + TTS	Change voice	Responses use selected voice	Medium	
TC-225	Main Integration	Preferences after restart	Restart application	Preferences loaded correctly	High	
TC-226	Main Integration	Activity logging after command	Execute command	Log entry created	High	
TC-227	Main Integration	Multiple modules together	Launch app then website	Both operations succeed	Medium	
TC-228	Main Integration	Invalid command flow	Speak invalid command	Error spoken and logged	High	
TC-229	Main Integration	Consecutive commands	Execute 10 commands	All processed correctly	Medium	

TC-230	Main Integration	Background execution	Run assistant for long time	Stable execution	High	
TC-231	Security	Invalid email password	Login with wrong password	Login denied	High	
TC-232	Security	Missing microphone permission	Disable permission	Error displayed	High	
TC-233	Security	Registry access denied	Block registry access	Proper error handling	High	
TC-234	Security	File permission denied	Access protected file	Access denied message	High	
TC-235	Security	Invalid website URL	Open malicious URL	Blocked or handled safely	Medium	
TC-236	Security	Invalid voice input	Speak random data	No crash	Medium	
TC-237	Security	SQL/script injection text	Speak SQL keywords	Treated as plain text	Medium	
TC-238	Security	Corrupted configuration	Damage config file	Recovery or default settings	Medium	
TC-239	Security	Unauthorized setting change	Non-authenticated user modifies settings	Action denied	Medium	
TC-240	Security	Unexpected shutdown	Force close application	No data corruption	High	
TC-241	Performance	Startup performance	Launch NOVA	Starts within acceptable time	High	
TC-242	Performance	Voice recognition speed	Speak command	Recognition within expected time	High	

TC-243	Performance	Application launch speed	Open Calculator	Opens quickly	Medium	
TC-244	Performance	Website opening speed	Open Google	Browser opens quickly	Medium	
TC-245	Performance	Email loading speed	Read inbox	Inbox loads efficiently	Medium	
TC-246	Performance	File search performance	Search large directory	Search completes efficiently	Medium	
TC-247	Performance	Reminder execution accuracy	Wait for reminder	Reminder triggers on time	High	
TC-248	Performance	Memory usage	Use NOVA continuously	Memory remains stable	Medium	
TC-249	Performance	CPU usage	Execute multiple commands	CPU usage acceptable	Medium	
TC-250	Performance	Long-duration execution	Run NOVA for several hours	No crash or freeze	High	
TC-251	End-to-End	Complete application startup	Launch NOVA	All modules initialize successfully	High	
TC-252	End-to-End	Open application using voice	Say "Open Notepad"	Voice → Command → Registry → Notepad opens	High	
TC-253	End-to-End	Open website using voice	Say "Open YouTube"	Website opens in browser	High	
TC-254	End-to-End	Send email using voice	Compose and send email	Email sent successfully	High	
TC-255	End-to-End	Read unread email	Say "Read my emails"	Emails read aloud	High	

TC-256	End-to-End	Create reminder	Set reminder	Reminder saved and triggered	High	
TC-257	End-to-End	Create timer	Set timer	Timer starts and completes	High	
TC-258	End-to-End	Open folder	Say folder name	Folder opens	High	
TC-259	End-to-End	Delete file	Confirm deletion	File deleted successfully	High	
TC-260	End-to-End	Sleep then Wake	Sleep → Wake command	Assistant resumes correctly	High	
TC-261	UAT	First-time installation	Install NOVA	Installation successful	High	
TC-262	UAT	First launch	Launch after installation	Welcome message displayed	High	
TC-263	UAT	Normal daily usage	Execute common commands	All work correctly	High	
TC-264	UAT	Beginner usability	New user performs commands	Easy to operate	Medium	
TC-265	UAT	Settings modification	Change settings	Changes applied correctly	Medium	
TC-266	UAT	Voice interaction	Use only voice	Tasks completed successfully	High	
TC-267	UAT	User satisfaction	Perform major functions	Expected behavior achieved	Medium	
TC-268	UAT	Help information	Request help	Help information displayed	Low	
TC-269	UAT	Error messages	Cause invalid action	User-friendly error shown	Medium	
TC-270	UAT	Exit application	Close NOVA	Application closes safely	Medium	

TC-271	Regression	Voice recognition after update	Test recognition	Still functions correctly	High	
TC-272	Regression	Registry launcher after update	Launch applications	Works correctly	High	
TC-273	Regression	Website opening after update	Open website	Successful	Medium	
TC-274	Regression	Email module after update	Send email	No regression found	High	
TC-275	Regression	File operations after update	Rename/Delete files	Work correctly	High	
TC-276	Regression	Reminder after update	Trigger reminder	Reminder functions correctly	Medium	
TC-277	Regression	TTS after update	Read response	Speech output correct	Medium	
TC-278	Regression	Sleep/Wake after update	Sleep then Wake	Works correctly	Medium	
TC-279	Regression	Preferences after update	Restart application	Preferences retained	Medium	
TC-280	Regression	Logging after update	Execute command	Logs still generated	Medium	
TC-281	Boundary	Empty voice command	Stay silent	Prompt for input	Medium	
TC-282	Boundary	Maximum command length	Speak very long command	Handled without crash	Medium	
TC-283	Boundary	Long email subject	Compose long subject	Stored correctly	Medium	
TC-284	Boundary	Long email body	Compose large email	Sent successfully	Medium	

TC-285	Boundary	Very long filename	Open file	Opens successfully	Low	
TC-286	Boundary	Maximum reminder text	Create long reminder	Reminder saved	Low	
TC-287	Boundary	Large activity log	Execute many commands	Logging continues	Medium	
TC-288	Boundary	Multiple scheduled reminders	Create many reminders	All saved successfully	Medium	
TC-289	Boundary	Large inbox	Read thousands of emails	Performance acceptable	Medium	
TC-290	Boundary	Continuous voice session	Run for several hours	Stable operation	High	
TC-291	Recovery	Restart after crash	Force crash then restart	NOVA starts normally	High	
TC-292	Recovery	Recover preferences	Restart after failure	Preferences restored	High	
TC-293	Recovery	Recover reminders	Restart application	Reminders retained	High	
TC-294	Recovery	Recover logs	Restart after error	Logs preserved	Medium	
TC-295	Recovery	Network recovery	Restore internet	Online features resume	Medium	
TC-296	Compatibility	Windows 10	Test on Windows 10	All features work	High	
TC-297	Compatibility	Windows 11	Test on Windows 11	All features work	High	
TC-298	Compatibility	Different microphones	Use USB/Bluetooth mic	Voice recognized correctly	Medium	

TC-299	Compatibility	Different browsers	Change default browser	Websites open correctly	Medium	
TC-300	Final Validation	Complete system verification	Execute all major features sequentially	Entire NOVA system works as expected without critical defects	High	